

Tahoe LOFT installation with Troy Cargo Containment Partition

1. Remove D-Pillar factory trim panels and install p/n TAH-LOFT-2 "L" mounting brackets using seatbelt holes and bolts supplied. Refer to LOFT installation instructions.
2. Reinstall trim panels and loosely attach p/n TAH-LOFT-1.
3. Cut out Troy side panels as shown in picture below.
4. Install Troy Cargo Containment per instructions.
5. Install LOFT per instructions.

