



3175 MACARTHUR BLVD. • NORTHBROOK, IL • 60062  
847-459-1460 • FAX 847-714-9443  
www.lund-industries.com  
www.data-carts.com

## LGV-QCPU-\* Mounting Instructions

REV 9/22



### CAUTION:

Always check before drilling or screwing to be certain not to hit anything (fuel tank, lines, wiring, etc) beneath the carpet, the transmission hump or the vehicle.

- Designed to mount under the rear bench seat of the Ford F150 or Chevy Silverado
- Position Vault in vehicle to the desired location
- Determine locations for supplied mounting brackets.

### Chevy:

1. Attach brackets to vault box using 3/8" carriage bolts with washers & nuts inside of box (Leave Loose)
2. Position Vault under rear seat.
3. Attach brackets to factory seat bolts.
4. Tighten all hardware



### Ford:

1. Position Vault under rear seat.
2. Use existing holes on seat rails that match up with slots on the back of the vault & install bolts, spacers, washers and nuts.
3. Holes can be drilled in seat rails using 5/16" drill bit if needed for alignment.
4. Tighten all hardware.



*3 Bolt / Spacers sets are supplied*