



THE LOFT

STORAGE AND EQUIPMENT COMPARTMENT

US PATENT No. 10,105,998

Installation Instructions

2020 Ford Police Interceptor Utility

LOFT-PIU20-GVT

Requires LOFT-PIU20-NPKIT

Note: Read standard LOFT and Troy instructions to familiarize yourself with the installation of each product.

1. Install the rear seat portion of the Troy Partition according to their instructions. Do not install side window panels at this point.
2. If Troy Partition is already installed you must remove the driver and passenger side window panels and (4) Troy mount brackets. Shown in (Fig.1)
3. Remove each factory d-pillar trim panel to access 3rd row seatbelt bolt holes. (Fig. 2)
*****Optionally you can drill a 1" hole as shown in Fig. 2 to access the seatbelt weld nut.**
4. Use supplied self-threading bolts and washers to mount LOFT "L" bracket as shown in pic (See Fig. 3)

FIG. 1



**TROY BRACKETS
(NOT TO BE USED)**

FIG. 2



FIG. 3



5. If removed now re-install plastic D-Pillar trim panels.
6. Install the LOFT using the provided **LOFT-PIU20-GV** & **LOFT-PIU20-NPKIT** Instructions.

Important : When Installing LOFT frame mount bracket (**PIU20-LOFT-DR** and **PIU20-LOFT-PR**) Be sure to add supplied "L" bracket to bolt to Troy side window guards. Using supplied 5/16" – 18 Hex Head Bolts, Nuts and Washers. (Shown in Fig. 4 & 5)

7. Once LOFT is installed, Install Troy side window panels (Shown in Fig. 5)
8. Install provided rear partition "Z" brackets. These reinforce the Troy rear partition. 2 bolts go into the slotted section on the LOFT and you will need to drill 2 holes on the Troy partition for each bracket. (Shown in Fig. 6)

Be certain that there is clearance so that the LOFT opens and closes easily without rubbing on the Troy Partition.

FIG. 4



FIG. 5



FIG. 6

