



3175 MACARTHUR BLVD. • NORTHBROOK, IL • 60062  
 847-459-1460 • FAX 847-714-9443  
 www.lund-industries.com  
 www.data-carts.com

## PASS-2-FPI-U16 Police Audio visual Safety System Installation Instructions 2016 Ford Interceptor Utility



- 1: Remove factory front fascia.
- 2: Mount 2 large PASS brackets with supplied 3/8-18 x 2" hex bolts. Leave loose for adjustment. **(Figure 1)**
- 3: Loosely attach back stiffening bracket. **(Figure 2 & 3)**
- 4: Attach top and bottom brackets and **check with assembled PASS bumper for proper fit.**
- 5: Fully tighten each large PASS bracket to vehicle bumper.
- 6: Remove top and bottom bracket from each side and set aside for later.
- 7: You are now ready to reinstall factory fascia back onto vehicle, (you will need to notch plastic on lower grill and factory plastic bumper reinforcement). **(Figure 4 & 5)**  
 Have an extra set of hands to help guide the fascia back on. Leave loose until step 8 is complete.
- 8: Attach the top brackets to the top portion of large PASS brackets and the back stiffening bracket with supplied 3/8" hex bolts and washers. Leave loose for later adjustment.
- 9: Finish attaching factory fascia by reinstalling all factory hardware and tighten securely.
- 10: Loosely attach bottom brackets to bottom portion of large PASS brackets.
- 11: Install assembled PASS Bumper and secure with remaining 3/8" hardware. Level and fully **tighten all hardware for final fit.**

