



---

3175 MacARTHUR BLVD. • NORTHBROOK, IL • 60062  
847-459-1460 • FAX 847-714-9443  
www.lund-industries.com  
www.data-carts.com

---

## RAM-SSV-BASE

1. Locate (3) factory pems on floor.
2. Locate factory hole that is open and missing a pem. Drill out hole with a 7/16" drill bit. Install Jack-Nut with supplied tool
3. For use when installing a limited quantity of Jack-Nuts.  
Place the wrench between screw and head of insert,  
hold wrench and run in screw to set Jack-Nut.



4. You can now install the (2) bale brackets to the floor with the supplied hardware.
5. Align base plate adapter bracket and tighten where desired.
6. Mount console in desired location.

**CAUTION:** Always check before drilling or screwing to be certain not to hit anything (fuel tank, lines, wiring, etc) beneath the carpet, the transmission hump or the vehicle.