



303 MESSNER DR. • WHEELING, IL • 60090
847-459-1460 • FAX 847-459-1569
WWW.LUND-INDUSTRIES.COM

04/17

SSTB-FPI-U 2015+ Ford Utility SecureStor Trunk Box Instructions



31" x 40"

CAUTION: Always check before drilling or screwing to be certain not to hit anything (fuel tank, lines, wiring, etc) beneath the carpet, the transmission hump or under the vehicle.

Rear Mounting: Remove rear threshold plastic trim. Screw small bracket into floor with supplied metric flange bolts and washers as shown in **Figure 1**.
Notch out plastic trim as needed. **Figure 2**.

Attach flat brackets to the bottom of the supplied rail using 3/8" carriage bolts and leave loose for rail adjustment as shown in **Figure 3**.

Front Mounting: Remove third row seat belt cover from floor (seat belt not supplied in FPIU model). Cut out plastic where "L" bracket will be mounted as shown in **Figure 4**.
Remove factory crash protection bolts (1 per side) and attach "L" bracket with factory hardware as shown in **Figure 5 and tighten securely**.
Put second rail in and leave loose for adjustment as shown in **Figures 6 & 7**.

Use 2 people to lift the SSTB into vehicle. Align and square up box with rear hatch opening. Securely tighten all nuts and bolts.

Be certain spare tire jack is accessible before installing vault. For access to spare tire, wing bolts can be substituted for 3/8" bolts on (4) side mounting points. Remove wing bolts and slide vault forward.

