



3175 MacARTHUR BLVD. • NORTHBROOK, IL • 60062
847-459-1460 • FAX 847-714-9443
www.lund-industries.com
www.data-carts.com

SSTB-GRCHK

1. Remove plastic trim panel in rear of vehicle and remove **(2)** factory nuts. **(See fig. 1)**
2. Place bracket in vehicle and secure with factory nut. Adjust height accordingly with the 3/8" carriage bolt and securely tighten. Repeat same process on other side. **(See fig. 2)**
3. Gently place factory trim panel in vehicle and mark locations to be notched for each bracket.
(See fig. 3)
4. Remove factory rear seat spring loaded cover by gently pulling up. **(See fig. 4)**
5. Remove the factory seat bolt and place in bracket and leave loose for later adjustment. Repeat same process on other side. **(See fig. 4)**
6. Place both rails in vehicle. Center and tighten with supplied 3/8" nylock nuts and washers. **(See fig. 5)**
7. Double check and properly torque each nut and bolt.
8. Place the SSTB-GRCHK in vehicle and securely attach with supplied 3/8" bolts and washers.

Fig. 1



Fig. 2



Fig. 3



Fig. 4



Fig. 5

