



303 MESSNER DR. • WHEELING, IL • 60090  
847-459-1460 • FAX 847-459-1569  
WWW.LUND-INDUSTRIES.COM

## VH-CHGR2410 Console Mounting Instructions



**Caution:**  
Be sure wire looms are run out of the way of console bottom plates so that they are not pinched or crushed.

**Caution:**  
On some vehicles, there is a sensor located in this area which should be removed and velcroed to the inside of the console bottom mounting plate

1. Remove factory mounted console or base plate from vehicle.
2. Remove factory nuts and bolts.
3. Set Lund console in place over the factory studs. Use factory nuts and bolts to securely fasten console.  
**Note:** Be certain not to crush any wiring beneath vehicle carpet or mat.  
**Tip:** Use fender washers as shims on factory bolts if leveling is required
4. **Option:** Lund console has a square hole on passenger side for use of factory auxiliary MP3 outlet found in lower dashboard. This can be removed from dash & installed in console.
5. Install supplied side skirts on each side of console using bolts. A hole may need to be drilled to position properly. The sides can be formed slightly to fit vehicle contour.